



800-487-7432

828-820-8600

Sports Hydration & Cooling Equipment Since 1999

# **Sports Cool Rolling Powered Team Drinker**



### Sports Cool Rolling Powered Team Drinker

#### PORTABLE WATER CHILLER

#### **ASSEMBLY OF YOUR SPORTS COOL - WATER CHILLER**

- **STEP 1)** Unpack the Cart (*item A*) and attach the Water Manifold (*item C*) to the cart using the Tension Bands (*item G*) and bolts, washers and locknuts (*items N,O,P*) as shown in diagram.
- **STEP 2)** Secure Water Tank (*item D*) to Cart using the Tie Down Strap (*item J*); locate as shown in diagram.
- STEP 3) Connect the Male Hose from Tank to the Female Hose on the Water Manifold.
- STEP 4) Now connect the Female Hose from Tank to a Sanitary water supply hose.

#### **OPERATING INSTRUCTIONS**

- 1) Fill Chiller Tank to full capacity with ice. As water flows through the Copper Coil Assembly (*item H*) it will become chilled. Replace ice in Tank as needed.
- 2) CAUTION DANGEROUS DISEASES CAN BE TRANSMITTED BY DRINKING CONTAMINATED WATER. CLEAN AND PROPERLY SANITIZE AND FLUSH SYSTEM AFTER EACH USE. SANITIZE DRINKING WANDS AFTER EACH USE.
- 3) Drain all water and remove lid from Chiller Tank when not in use.
- 4) Drain water from drinking wands when not in use.

ITEM	DESCRIPTION	QTY	PART#
Α	2 WHEEL HYDRATION CART	1 EA	ZDRINK2WHL
В	MALE HOSE CONNECTOR	1 EA	ZX3920106
С	WATER MANIFOLD	1 EA	ZSPCDMA
D	WATER CHILLER TANK ASSEMBLY	1 EA	ZSPCCOIL2
E	FEMALE HOSE CONNECTOR	1 EA	ZX3920104
G	TENSION BAND	2 EA	ZX0900098
Н	COPPER COIL - ONLY	1 EA	ZX3920045
J	TIE DOWN STRAP	1 EA	ZX3900040
K	COIL HOSE ASSEMBLY	6 EA	SPCHOSE
L	WATER WAND #6	6 EA	ZX3920080
M	POLY TRIGGER VALVE	6 EA	ZX3920038
Ν	HEX BOLT 1/4" X 1"	2 EA	Z041250100
0	FLAT WASHER 1/4"	4 EA	Z070025Z/P
Р	LOCK NUT 1/4"	2 EA	Z060250XXX

## **Sports Cool Rolling Powered Team Drinker**

